




PAKOLE

USER'S MANUAL

(For users)

AIR HEATERS WITH PROPANE OR NATURAL GAS



Appliance types:

LH-40
LH-50
LH-60
LH-70
LH-80
LH-90
LH-100

LH_008_030_011_260707_V007_EN

www.pakole.com

EN

Table of Contents

1. SAFETY INFORMATION	3
2. GENERAL INSTRUCTIONS.....	4
Data board.....	4
Installer's responsibilities.....	4
Corrosive materials	5
Standards and laws	5
Safety signs	5
Safe usage	5
3. TRANSPORT, UNPACKING, HANDLING	6
4. OPERATING PRINCIPLE	7
The gas supply system.....	7
The air supply system	7
The ignition system	7
Safety monitoring and intervention systems	7
LH air heater	8
5. INSTALLING THE DEVICE	8
Gas connection	9
Supply of air	10
Installation of the device	10
Suspension	11
LH air heater dimensions per type.....	11
Electrical connection	12
6. CONTROLLING THE DEVICE.....	13
7. OPERATION	13
Starting the device	13
Error detection (RESET)	14
Switching off the equipment	14
7. MALFUNCTIONS AND TROUBLESHOOTING	15
8. MAINTENANCE	15
Maintenance operations	15
Gas exchange	16
9. TECHNICAL PARAMETERS	16
10. ANNEXES	17
Annex 1: LH air heater performance data and gas consumption	17
Annex 2: Air delivered by LH air heater.....	17
Annex 3: Number of burners for LH air heater.....	17
Annex 4: Ventilation demand of LH appliances in the room in m ³ /h.....	18
11. GUARANTEE AND SERVICES	19

1. SAFETY INFORMATION



ATTENTION! Read and understand this Installation and Maintenance Instruction before using the equipment! Keep this Installation and Maintenance Guide to answer any questions you may have later!

GENERAL SAFETY WARNINGS!

Failure to follow the warnings and instructions in the enclosed Installation and Maintenance Manual may result in serious injury or property damage.



The appliance may only be used by persons who have understood and followed the instructions in the Installation and Maintenance Manual! If you need help or information about the heater, such as installation instructions, contact the manufacturer.

This appliance is not intended for use by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, including children. Children should be supervised to ensure that they do not play with the appliance.



WARNING! Fire, burn, inhalation and explosion hazard! Keep combustible materials such as building blocks, paper or cardboard boards at a safe distance from the heater according to the instructions! Never use an open system appliance in a room where flammable volatile substances or the following products are present or may enter the appliance: petrol, solvents, thinners, granular dust or unknown chemicals!



ATTENTION! The appliance must not be used at home! Do not use in a closed, unventilated area!

WARNING!

For your own safety, if you smell gas, do the following:

Turn off the gas valve!

Open the windows.

Do not try to turn on the lights or turn on any appliances.

Do not use any electrical switches.

Do not use any telephone in the building.

Leave the building.

Call your local gas company after leaving the building. Follow the gas company's on-call instructions.

If you cannot reach the gas company, call the fire department.

The LH appliances have been developed and certified in compliance with EN 17082:2019 standard and qualified for heating of industrial rooms! The function of these heater appliances to ensure heating of appointed workplace temporarily or continuously! In case of proper using the appliance guarantees safety and energy-saving operation! The combustion products issued during combustion process leave through the flue system into the open air. In case of further possible questions regarding the applicability please turn to the local Fire Protection Office!

Other standards can give you directions in terms of proper using of natural and propane gas as follows: leading/piping, storing etc.! Concerning the detailed content of these standards the local Bureau of Standards can help.

Carbon- monoxide poisoning: The initial symptoms of carbon-monoxide poisoning are similar to influenza namely headache, dizziness and/or nausea! If these symptoms are observed in that case the appliance probably does not work satisfactorily! First of all go fresh air, ventilate the rooms and have the appliance investigated!

Propane-gas: The propane-gas odourless! Mercaptan-derivative as scented component is mixed into the gas to be able to observe the possible escape! In spite of the typical smell is not felt the propane gas can be present in the environmental air in case of escaping!

2. GENERAL INSTRUCTIONS

- During the installation be always circumspect! Follow the valid instructions and recommendations!
- The appliance can be operated by specified voltage and frequency marked on its data board! The electrical connections and groundings are prepared as per EN 60335 standard!
- Electrical grounding specification: present appliance is equipped with three points grounding connection in the interests of your protection!
- When used in confined spaces, adequate ventilation air must be provided.
- Use the equipment only in a well-ventilated room. The required combustion and ventilation air volume can be determined according to Annex 1.
- The appliance must not be used in the open air!
- Keep the equipment away from the following strong impacts: wind.
- The application of device is **STRICTLY PROHIBITED** in such rooms, which are used for sleep or continuous stay!
- Keep away the flammable materials from the appliance and its near environment as follows: fuels, thinner or other flammable fluids and vapours!
- Before starting of appliance in every case check it in order to detect the possible damages! Never use damaged equipment!
- In case of propane-gas operation never install the device in basement or from that lower being rooms! The propane-gas is heavier specific gravity than the air for this reason in case of possible escaping it will spread towards the lower located rooms!
- Only use that kind of flexible gas pipe and pressure regulator, which is offered for the appliance by the manufacturer!
- Before every starting of heater appliance check the condition of connecting gas hose and if it is particularly worn or damaged in that case exchange it for a new one specified by manufacturer!
- Preserve the equipment in genuine condition, do not leave it to worn!
- Do not use seriously worn equipment any longer!
- Hang the appliance on a stable surface that will maintain its stability during operation, even if the appliance heats up.
- Keep children away from the equipment.
- If the appliance is put out of use in every case it must be cut off the current and gas!
- Never block the air supply and exhaust pipes!
- Never service/mend such devices, which are hot and during operation or electrical charged!
- Never mount such air duct unit on front or back side of device!
- Use exclusively genuine-approved by manufacturer-spare parts, do not install similar quality spare parts for substitution! These kind of substitute parts can cause serious damages concerning the operation of appliance!
- **In all cases, install a pressure relief device recommended and approved by the manufacturer, with a minimum pressure of not less than 20 mbar and a maximum pressure of not more than 60 mbar.**

DATA BOARD

The device is equipped with a data board, which is located on the outside of the device. The data board contains information on the type of appliance, the type of gas and the electrical connection. For example:

Manufacturer PAKOLE Trade Kft. 8000 Székesfehérvár, Börgöndi út 8-10.		Type LH-70		 2806 20 PIN: 1008 CQ 2800 Date/place of production 15.02.2021
Electrical protection: IP44		Nominal input: 70 kW		
Electrical connection: AC 230V 50Hz		Pconnecting max.: 60 mbar		
Max.current entry: 2,1 A		Pconnecting nom.: 37 mbar		
Electrical power: 483 W		Airflow: 3600 m³/h		
Category: I2H, I3P, I2H3P		Targeted country: ES		
Series number: 37-249-2716		Gas type: PB		

Figure 1: Data board

INSTALLER'S RESPONSIBILITIES

- Gas and electrical connections are made in accordance with the regulations (it is recommended to contact the local building inspectorate or the Fire Brigade),
 - The installation of the apparatus in accordance with the layout described in this instruction manual,
 - Installation according to fire safety regulations,
 - The provision of materials (not included in the appliance) necessary for installation,
 - The design of ventilation, connections and ducts,
 - To carry out the servicing, to provide the Owner with the instructions for use supplied with the equipment
 - Ensuring sufficient air circulation around the unit,
 - Determining or providing the prescribed amount of air for combustion.

CORROSIVE MATERIALS



ATTENTION! Do not use the device in a place where there may be corrosive substances in the air!

The manufacturer accepts no liability for damage to the device if it has not been installed as described above. This responsibility is entirely the responsibility of the person performing the design. To avoid such possibilities, if you are not sure about the fit to the building or activity, ask our staff for help.

The owner(s) and the person(s) coordinating the installation must identify any gaseous or solid substances present in the space to be heated which may be present in the building and which could significantly affect the operation or service life of the appliance (combustible materials, corrosive substances, halogenated hydrocarbons, etc.) and then,

STANDARDS AND LAWS

All devices must be installed in accordance with laws and standards. These laws refer to electrical wiring (there are special regulations for parking garages, aircraft hangars, etc.).

SAFETY SIGNS




SAFE USAGE



Observe the following relevant rules during installation, adjustment and service:

- In all cases, the standards, regulations and country-specific regulations of the country of installation must be strictly observed during installation.
- Installation and maintenance of the device may only be performed by a qualified person.


A qualified person is any person who has significant technical experience in the field of gas-heating and ventilation installation and / or has a professional examination in the field, as well as has participated in the mandatory annual training organised by distributor. Call your nearest distributor for information.





- Depending on the design, install the electrical wiring system.
- Before starting the appliance, always make sure that the appliance and its electrical components are properly earthed.



- If you disassemble the equipment, use protective gloves!
- Be careful of sharp corners!
- Watch out for roof pitches on externally installed appliances!
- Always keep the intake vent clean!



- Before cleaning or maintenance operations that can be performed by the customer (see chapter 8), after disconnecting the power supply, make sure that the fan has stopped rotating automatically. (Do not stop the still running fan by hand or other means!)
- The fan can reach 1000 RPM so don't put anything in the way of the blades.



- We recommend that you install a separate, easily accessible disconnect switch near the machine to easily unplug the machine. Always unplug the appliance before cleaning or servicing.
- Before opening the appliance, make sure that all its components have been electrically disconnected from the mains. Take special care to make sure that the fan is stationary and cannot start during the installation process.

CHECK EARTHING !!



- This equipment is designed for heating - ventilation tasks. Any other use is not permitted and may be dangerous.
- When used in the vicinity of persons with reduced mobility, the device must be placed at a suitable, inaccessible distance from these persons.
- Improper installation can cause environmental or personal damage. The manufacturer is not responsible for damage resulting from such faulty installation.
- Furthermore, the manufacturer cannot be held responsible for damage resulting from incorrect, improper use.



- Never use the appliance in connection with another appliance.
- Never leave tools or accessories inside or on top of the appliance.
- Ensure that all test doors are properly closed.
- Do not place the device in a flammable environment.



- In the event of a malfunction, do not attempt to service the device, call your distributor immediately.
- If you want to leave the unit turned off for an extended period of time, make sure that it cannot harm anything or anyone under any circumstances.

3. TRANSPORT, UNPACKING, HANDLING

- The transport must be carried out as follows :
 - Packages must be properly secured in the hold.
 - Packages should be transported protected from the weather, preferably in a closed hold.
- The device is equipped with special transport packaging suitable for transport, which must be kept in good condition until the date of delivery to the installation site.
- Check that the device contains all the parts and accessories included in the order.
- Check that the appliance is not damaged and that its type corresponds to the type ordered. All devices are shipped from the factory after testing, so if you notice any damage, notify your carrier immediately.

Transporting, unpacking and packing the device is a process that must be carried out with special care to avoid possible damage. Do not attempt to use the components of the device as a handle. When lifting, make sure that the centre of gravity of the package is at the centre of the lifting fork of the lifting machine.



The device is delivered in a corrugated cardboard box on a pallet. The process of unpacking the device:

- remove the appliance, tubes and assembly materials from the paper boxes,
- **do not remove the protective caps until the gas is connected to the appliance,**
- check the condition of the appliance, pipes and fittings,
- in the event of damage to the equipment, immediately notify the retailer from whom you purchased the equipment.

Inside the device, you will find the Installation and Maintenance Manual, the User's Manual, the Warranty Certificate and the Installation and Operation Manual.

4. OPERATING PRINCIPLE

THE GAS SUPPLY SYSTEM

For safe operation of the appliance, the gas network must have a minimum pressure of 20 mbar and the network pressure must not exceed 60 mbar.

After connecting the gas connection kit to the gas mains and opening the ball valve, the gas flows through the gas filter and the double-closing combined gas solenoid valve through the nozzle bores into the firebox.

THE AIR SUPPLY SYSTEM

The motor turns the fan blades, which create the right airflow inside the appliance. The resulting air flow carries with the heat generated by the combustion of the gas-air mixture and the combustion products.

THE IGNITION SYSTEM

Depending on the need for heating, the control electronics sends an electrical high-voltage signal to the spark plug when heating is required, causing it to spark and ignite the gas-air mixture.

SAFETY MONITORING AND INTERVENTION SYSTEMS

The device is equipped with a three-point safety system for your (the user's) safety.

- Ionisation flame detector
- airflow detector
- safety temperature limiter

In certain countries, depending on the regulations, may require the use of a four-point safety system, which in addition to the above-mentioned monitoring and intervention systems, also requires the use of a intake gas pressure sensor.




Figure 3: Cross-sectional image + operating principle




Figure 4: Burner head + safety units (for small and large burner groups)

5. INSTALLING THE DEVICE

LH AIR HEATER




Figure 5: Main structural elements of the LH air heater

GAS CONNECTION

WARNING! The appliance may only be used with the type of gas indicated on the data plate of the appliance!



WARNING: Air heaters of type LH-... may only be used with the type of gas indicated on the data plate of the appliance.

Nominal connected gas pressure for natural gas: 20 mbar

Nominal value of the connected gas pressure for propane: 37/50 mbar

Maximum connected gas pressure: 60 mbar



WARNING! If the pressure of the gas supply is higher than 60 mbar, the use of a pressure regulator is essential, because the maximum allowable pressure of the double-closing solenoid valve is $P_{max} = 60$ mbar.

The pressure regulators can be installed individually in front of each appliance or 1 centrally on the main gas line.

Individual, that means, if a pressure regulator is installed directly in front of each appliance, only in front of the pressure regulator, if a central pressure regulator is used, the installation of a gas filter in front of the pressure regulator and each appliance is mandatory!

The installation of a gas filter is mandatory in order to avoid blockage or clogging of the pressure regulator and the gas solenoid valve of the appliance, which can be caused by possible deposits in the pipe (even if the gas line is blown out). The gas mains must be connected from above or from the side, because a connection from below serves as a collection point for dirt, which affects the correct functioning of the appliance.




Figure 6: Connection to the main pipeline

When designing the connection, the thermal expansion of the appliance must be taken into account, so the gas connection should be made with a flexible hose. Use a flexible hose when designing the connection to allow 100 mm of free expansion.



Install the hose without twisting!

The pressure regulator can be installed before each appliance or centrally namely one piece into the gas-supply pipe. In case of unique solution - namely there is pressure regulator before each appliance – before every pressure regulator, in case of centrally mounted pressure regulator before pressure regulator and each appliance **MUST BE INSTALLED GAS FILTER** to be able to avoid the blocking of appliance's gas magnetic valves, which can be caused by possible contamination settled in the supply pipes (Despite blowing out of pipes it can be present).




Figure 7: Gas connection kit

Operations to be performed:

- Cleaning of gas pipelines:

Before the appliance is connected to the gas mains, it is important to clean the gas mains completely and thoroughly.

- Gas tightness check:

After connecting the appliance, make sure the gas connection pipe is tight. This operation must be carried out after each disassembly and assembly.

SUPPLY OF AIR



WARNING! Always comply with the minimum fresh/ventilated air requirements. If the required amount of fresh/ventilated air is not provided, carbon monoxide poisoning may occur. Always ventilate thoroughly before starting up the equipment.

DETERMINE THE AMOUNT OF FRESH/VENTILATION AIR REQUIRED:

In accordance with the relevant standard specifications, the fresh air requirement can be determined as follows:

$$(L + Q \cdot C_v \cdot T \times 10^{-3}) \times \frac{110}{100} \times \frac{103}{100} = N \cdot Q \times 10^{-3}$$

$$Q = \frac{1130 \cdot L}{(N - 1,13 \cdot C_v \cdot T)}$$

L – structural heat loss (MJ/h)

Q – (=AV) the volume of air exchange m³/h

N – the maximum allowable thermal input = 86kJ/m³

C_v – specific heat content of air = 1,207kJ/m³K

T – the temperature difference in Kelvin

110/100 factor gives a 10% bonus for rapid warm-up

A factor of 103/100 provides a 3% bonus for losses attributable to the chassis


A sample of the sizing procedure with the definition of the supplementary heating requirements is given in Annex 1.

INSTALLATION OF THE DEVICE



The installation must comply with the regulations and rules in force in the area and the installation must be carried out in accordance with these regulations and rules when installing the appliance. The installer shall carry out the mandatory gas tightness test on the gas appliance inlet pipe. Before installation, the local conditions, gas type and pressure must be checked to ensure that the appliance is set up in accordance with these.

SAFETY AND FIRE DISTANCES FROM COMBUSTIBLE MATERIALS:



Capacity (kW)	Safety distances (mm)			
	A	B	C	D
40 kW	400	1350	500	500
50 kW	450	1500	500	500
70 kW	500	2000	1000	750
80 kW	600	2500	1000	1000
90 kW	600	3000	1000	1000
100 kW	600	3000	1000	1000

Table 1: Safety distances from device power performance

Figure 8: Safety distances



The safety distance from the wall is equal to the "C" safety distance!


LH AIR HEATER DIMENSIONS PER TYPE

Figure 9: Air heater dimensions per type

SUSPENSION

Once you have determined the exact locations of the devices and the brackets, you must ensure that they are mounted on suspension chains of the appropriate length. The minimum length of the chain must match the length D in the table on page 10; the maximum length may be 2 m.

The hangers can be attached under the ceiling or roof structure, under support rods or scaffolding, between columns, next to walls, on brackets, etc. The device is suspended using the mounting holes located at both ends of the device and the mounting eye located at the front of the device.

When designing the suspensions, the back tilt of the device must also be taken into account. In all cases, horizontal placement is recommended, with a maximum deviation of $+5^\circ$.

It is important to note that the suspension chain absorbs vibrations during operation of the device. Therefore, the chain suspension must not exceed a length of 2 m. For higher suspensions, the fixed support structure must be combined with the chain suspension.

CAUTION! The flexible acid-resistant gas hose must not be subjected to any force, oscillation, or vibration from any device!

Flexible gas hoses can be up to 2 m long. At this length, the hose can absorb vibrations during operation and cause serious oscillations in the hose, which can lead to thermal breakage. To prevent this, it is advisable to secure the hose to a fixed point at a few points to prevent this type of vibration, as the gas hose may break in the long term!




Figure 10: Maximum inclination of the device

ELECTRICAL CONNECTION

The axial fan for combustion air and air flow, as well as the electronics, require 230V/50Hz /2A mains voltage.

**WARNING:**

- The equipment must be connected to the mains supply by means of a safety plug on the control unit (box).
- A circuit breaker must be installed into the electrical network front of the appliance.
- Ways of connecting to the network:
- Grounded plug-in forks or fixed wiring can be done in phases.
- The EPH point of the equipment must be connected to the EPH network of the building!
- Power supply cable: 3-pinned MT cable.
- The device is phase sensitive, so always connect as indicated.
- Fuse: 10 A small circuit breaker.

The instructions for Y-connected appliances shall include the essentials of:

If the mains lead is damaged, replacement should be carried out only by the manufacturer, its service agent or other suitably qualified person to avoid any risk.

Appliances fitted with a mains connection lead and appliances intended for permanent connection to a fixed wiring network which are connected to the network by a flexible lead shall have a lead strain relief device.





Figure 11: Wiring diagram for connection to the electricity network



6. CONTROLLING THE DEVICE

The air heater type LH can be controlled by a central or individual temperature controller mounted on the heater. If there is a central temperature control in the room to be heated, an individual temperature control is not necessary and is therefore not fitted at the factory.

In case of individual control, the temperature control is located on the side panel of the control box, in front of the air flow fan. Control range: 0-40°C

The temperature is automatically controlled by switching the appliances on and off according to the room air temperature and the temperature values preset on the temperature controller. The equipment can be fitted with an external temperature controller, the correct connection points for which are given in Annexes 7 to 8.

The equipment can be operated in three ways:

- VENTILATION ONLY
- CONTINUOUS VENTILATION + HEATING
- HEATING ONLY

VENTILATION ONLY

In this case, the room does not require heating, but a fan is needed either for air exchange or to move the air in the room. Turn the lower on/off switch of the two switches on the side of the control box to the 'on' position. The switch above it The 'heating - ventilation' and 'heating' switches located above the control box are set to 'heating - ventilation'. Set the thermostat for temperature adjustment to minimum. In this position, the appliance will only ventilate.

CONTINUOUS VENTILATION + HEATING

The position of the switch corresponds to the „ventilation only” mode, except that the thermostat must be set to the desired temperature. If the room temperature drops below the set value, heating is started, if no heating is needed because the thermostat has reached the set value, only ventilation is started.

HEATING ONLY

Turn the on/off switch on the control box to the „on” position and the two-position switch above it to the „heating” position. In this case, the appliance will heat the room to the temperature set by the thermostat and when the set temperature is reached, the heating will be switched off and the ventilation will stop.

7. OPERATION

STARTING THE DEVICE

If you have selected the desired mode from the list, set the switch to the appropriate position and the appliance will start the requested programme according to the instructions.

According to the instructions you have given, the fan will either run continuously or start at the same time, depending on the heating need. In all cases, the need for heating is detected by the temperature controller and the ignition process is started at the appropriate moment. In all cases, the ignition process is started with a 30 sec pre-ventilation. During this pre-ventilation period, the airflow switch detects whether the fan is operating correctly and is able to generate the correct airflow. If the air flow switch detects the correct air flow and the 30 sec pre-ventilation time has expired, the electronics will trigger the spark ignition and simultaneously open the double closing combination solenoid valve. The gas is fed through the pipes and nozzles to the spark plug, where it ignites the gas-air mixture. If the ignition process has been successful and the ionisation flame detector detects a continuous flame pattern, the appliance is in operation and performs its heating function.

In some countries where the use of a gas pressure sensor is required by regulations, it is part of the ignition process that the appliance cannot start until the gas pressure sensor, set according to the local pressure value, detects the predetermined pressure value. The gas pressure sensor is interlocked with the control electronics and if at any time during operation a pressure fluctuation or gas shortage occurs that causes the gas pressure to fall below the preset value, the gas pressure sensor will immediately disable the electronics and the appliance will stop.

ERROR DETECTION (RESET)

During the normal use of the equipment and during start-up, a number of faults may occur. These faults are monitored and detected by various monitoring and intervention safety units. As a rule, three points ensure the safe operation of the equipment:

- Air flow switch
- Ionisation flame detector
- Temperature limiter

Exceptions are appliances that are shipped to countries that require the use of a gas pressure sensor.

Each of the safety intervention units listed above is individually responsible for the safe operation of the appliance and is interlocked with the control electronics, which will immediately stop operation if any fault is detected.

AIR FLOW SWITCH

The airflow switch detects whether the fan has started and is able to deliver the right amount of air (motor not faulty, air intake side not blocked, etc.)

If the airflow switch does not switch to the closed position, the control electronics will stop the start-up process and the equipment will signal a fault (RESET), which will be indicated by the illumination of the RED lamp on the control panel.

The RESET button is pressed once to cancel the error message, the RED light goes out and the unit automatically restarts.



IONISATION FLAME DETECTOR

The function of the ionisation flame detector is to monitor the flame, the electrode detects the presence of the flame after sparking and monitors it continuously. If the flame is not stable after sparking or if the flame is cut off during operation, the flame detector immediately stops the appliance and signals a fault (RESET) by interlocking with the control electronics. The RED button on the control panel lights up. By pressing the RESET button once, the fault message is cancelled, the RED light goes out and the appliance automatically restarts. If it does not start, contact the service.



TEMPERATURE LIMITER

The temperature limiter is a sensor/intervention unit placed under the casing of the appliance, inside the appliance. Its function is to continuously monitor the internal temperature of the appliance and, if the temperature reaches 140°C, to immediately stop the heating by means of the control unit and interrupt the circuit of the automatic ignition control. Stopping the combustion does not stop the exhaust fan, which continues to operate and cools the appliance. Re-ignition of the appliance is automatic only after cooling back to operating temperature.

SWITCHING OFF THE EQUIPMENT

Turn the on/off switch on the control box to the „off“ position, close the gas shut-off valve in front of the appliance, disconnect the appliance from the mains.



WARNING! Always disconnect the appliance from the gas supply if the appliance is not to be used for a long period.

After disconnecting the appliance from the mains, replace the plastic protective caps removed during unpacking on the gas connection elements.

Always use new sealing rings when dismantling and reassembling the gas mains.

Always store the appliance in a dry, clean and safe place to avoid premature worn and to protect it from possible mechanical damage.

7. MALFUNCTIONS AND TROUBLESHOOTING

The following indicator light on the unit's control box indicates the air heater's operating status:

- RED: error indicator light
After resolving the error, press the RESET button.



WARNING! If the mains connection cable is damaged, replacement should be carried out only by a qualified person or by the service technician to avoid any risk.

8. MAINTENANCE



WARNING! In the event of prolonged interruption of the operation of the equipment always disconnect the appliance from the gas supply.

After disconnecting the appliance from the mains, replace the plastic protective caps removed during unpacking on the gas connector.

Always use new sealing rings when dismantling and reassembling the gas mains.

Always store the appliance in a dry, clean and safe place to avoid premature ageing and to protect it from possible mechanical damage.




WARNING! Never service an appliance that is live, connected to the gas mains, in use or still hot. The above can cause electric shock or burns.

MAINTENANCE OPERATIONS

The air heater type „LH“, when used in agriculture, does not require any special maintenance apart from the inspection and cleaning after each rotation (see maintenance operations that can be carried out by the customer), but to ensure the safety of operation and long life of the appliance, it is recommended that, at least once a year, it is inspected by a professional service technician or a specialist.

MAINTENANCE OPERATIONS THAT CAN BE CARRIED OUT BY THE CUSTOMER:

- Checking and cleaning the enclosure:
Dust the outside of the casing with a brush or air, then make sure there are no burn-outs, abrasions, etc.
- Visually check the condition of the flame trap disc through the exhaust outlet. Burn-out, discoloration is clearly visible.
- Check the suspensions, making sure the load is evenly distributed on all suspensions. You can check this by moving the suspension elements one by one.
- Axial fans should be cleaned with air.
- Check the status of the air flow switch operated by the axial fan of the air flow extinguisher, and its readiness for manual switching. Manually operate the micro-switch twice, three times. If necessary, clean with low air pressure.
- Water must not enter the device; the components shown in the image below are not waterproof. Water entering the device may cause it to malfunction or become inoperable, which will automatically void the warranty!



If the operating conditions of the device (environment with pollutants, e.g. dust, vapours, etc.) require it, inspection and cleaning operations should be carried out more frequently! The main reason for this is that dust deposits on the fans reduce the efficiency of the unit and can significantly increase its weight, which is an important factor for the safety of the suspension.

The appliance is suitable for heating greenhouses, agricultural livestock buildings, livestock buildings (poultry, pigsties, etc.).

Warning: If the appliance is used in an agricultural context (e.g. livestock farming, etc.) or in an area where flammable substances may be released into the air during the maintenance or cleaning of the site, it is strictly forbidden to operate the appliance during this period!

In the case of livestock farming, the unit must be cleaned after each rotation!



WARNING! Before any maintenance operation, switch the appliance off by turning off the main power switch. and unplugging the electrical plug on the back of the appliance, the appliance must be disconnected from the mains power supply.



WARNING! If the operating conditions of the instrument (environment with pollutants, e.g. dust, corrosive vapours) require it, inspection and cleaning operations should be carried out more frequently. should be carried out more frequently! The main reason for this is that dust deposits on the emitter body reduce the efficiency of the device and can significantly increase the weight, which is an important factor for the safety of the suspension.

GAS EXCHANGE



WARNING! If the appliance is to be operated with a different gas (e.g. propane instead of natural gas), always contact the distributor or a specialist workshop!



WARNING! This operation may only be carried out by a specialist service technician or a specialist authorised by the manufacturer.



WARNING! It is strictly forbidden to cover the fan or the exhaust outlet of the appliance!

9. TECHNICAL PARAMETERS

Fuel.....Natural gas, Propane

System pressure up to the solenoid valve:

Minimum.....20 mbar

Maximum.....60 mbar

Fan motor180 W

Electrical connection.....230V / 50Hz / 2,1A

Current consumption.....1,5 A

Weight (up to LH-60).....20,6 kg

Weight (from LH-70).....22,6 kg

ANNEX 1: LH AIR HEATER PERFORMANCE DATA AND GAS CONSUMPTION

CAPACITY AND GAS CONSUMPTION							
TYPE	LH-40	LH-50	LH-60	LH-70	LH-80	LH-90	LH-100
Power output [kW]	40	50	60	70	80	90	100
Natural gas [m³/h]	4,23	5,29	6,30	7,35	8,40	9,52	10,14
Propane [kg/h]	3,34	4,19	5,01	5,84	6,71	7,51	8,26

ANNEX 2: AIR DELIVERED BY LH AIR HEATER

VOLUME OF AIR DELIVERED							
TYPE	LH-40	LH-50	LH-60	LH-70	LH-80	LH-90	LH-100
Fan air flow [m³/h]							

ANNEX 3: NUMBER OF BURNERS FOR LH AIR HEATER

QUANTITY OF BURNERS							
TYPE	LH-40	LH-50	LH-60	LH-70	LH-80	LH-90	LH-100
Quantity of nozzles [pcs]	5	5	5	5	5	5	5
Natural Gas							
Nozzle pressure [mbar]	10	10	10	10	10	12,5	12,5
Propane							
Nozzle pressure [mbar]	20	20	20	20	20	20	20

ANNEX 4: VENTILATION DEMAND OF LH APPLIANCES IN THE ROOM IN M³/H

- a) 15m x 30m x 4m = 1800 m³
- b) Structural heat loss L = 264 MJ/h
- c) Designed for an internal temperature of 20°C with a minimum external temperature of -1°C T = 21°C

In this case, the volume of air exchange is as follows:

$$Q = \frac{1130 \times 264}{86 - [1,13 \times 1,207 \times 20 - (-1)]} = 5201 \text{ m}^3/\text{h}$$

The hourly air exchange rate is calculated for a room of 1800 m³ :

$$5201 \div 1800 \approx 3,0$$

With this calculation method the CO₂ concentration does not exceed the permitted 0.25% (V/V)!

The heat demand „H” of the supply air can be calculated using the following equation:

$$H = A \times V \times C_v \times T \times 10^{-3}$$

A – the number of air exchanges per hour

V – volume of room m³

C_v – specific heat content of air = 1,207 kJ/m³K

T – the temperature difference in Kelvin

$$H = 3 \times 1800 \times 1,207 \times 21 \times 10^{-3} \approx 137 \text{ MJ/h}$$

The total heat demand of the building is therefore:

$$137 + 264 = 401 \text{ MJ/h} \approx 112 \text{ kW}$$

GUARANTEE AND SERVICES

PRESERVE THIS WARRANTY

Type:

Serial no.:

Date of purchasing:

LIMITED GUARANTEE *

The manufacturer guarantee the costumer that the product and its parts are free from material and production failures. During normal use the warranty is 2 years. This warranty concerns the first retail customer.

The guarantee concerns the costs of laboratory investigations and the parts, which are needed for proper operation. The delivery and unforeseeable costs belong also to the mending costs and do not contain compensation costs.

Guarantee mending can only be realised by authorised retailer or service centre.

The guarantee does not concerns the following failures, which are caused by: improper using, damaging, neglect, accident, lack of maintenance, normal attrition, transformation, modification and operation influenceable factor, contaminated fuel, installation of non-suitable part and mending which is done by not authorised retailer or service station.

The regular maintenance is the owner's responsibility.

The manufacturer does not assume the responsibility in case of accidentally happened or directly caused mistake respectively improper using.

***We reserve the right to change of this specification without extra notification. The guarantee can be applied in accordance with above defined.**

Additional guarantee is not accepted.

Guarantee servicing

If your appliance needs guarantee service in that case it can be requested at nearest authorised service station giving in the appliance for repairs.

Mending services

Take the appliance to the nearest authorised service station. If the device is not under guarantee the service cost will be invoiced to the costumer at defined price. The service centres are independent from one another and may have different owners. We reserve the right to change of this specification without extra notification. If you would like to contact us the type and serial number of device always be at hand. In case of other needed information write to the distributor.



PAKOLE

www.pakole.com

PAKOLE TRADE Ipari és Kereskedelmi Kft.

H-8000 Székesfehérvár, Börgöndi út 8-10.

www.pakole.hu

mail@pakole.hu

Tel.: +36 22 316 484